

NetGear Router Install

(Supplement to pamphlet enclosed with router)

Establish hardwire connections

- Select a computer to use to configure the router
- Shutdown the computer
- Remove the Ethernet cable from the computer's Ethernet port
- Place that Ethernet cable in the WLAN Ethernet port on the router
- Connect the Ethernet port on the computer to one of the numbered Ethernet ports on the router
- Plug one end of the power cord into the router and the other into an electrical source

Configure the router.

- Power up the computer
- Open an Internet browser
- Browse to www.routerlogin.net – do not check for update
- Login
- Change admin password
- In Wireless Advanced LAN settings, DHCP is checked by default
- In Advanced (near the bottom of the left sidebar) > wireless > WPS settings, disable router PIN

Other configuration changes may be needed if static IP addresses are involved.